
Content

Content.....	1
Welcome to the Blu▶LYNC® Bluetooth Adapter.....	2
Blu▶LYNC® Features.....	3
Charging.....	4
How to turn the Blu▶LYNC® on/off.....	5
Connect Blu▶LYNC® with the audio accessory.....	6
List of Blu▶LYNC® functions, operations and status.....	7
Status of indicators.....	8
Specifications.....	9


Welcome to the **Blu▶LYNC®** Bluetooth adapter

Blu▶LYNC® is compact, lightweight and easy to use. Utilizing Low Energy Bluetooth V4.0 chipset it enables faster connections and clearer transmissions. Complete **Blu▶LYNC®** by pairing it with the Blu-PTT.

Please read this manual carefully before using the **Blu▶LYNC®** Bluetooth adapter.

BluLYNC® Features

1. USB Charging Port
2. Status LED
3. Power/Pairing button
4. Radio Connector



Charging

1. Please fully charge the **Blu▶LYNC®** adapter before using it the first time.
2. When the **Blu▶LYNC®** adapter is connected to the charger a solid red LED light indicates that the **Blu▶LYNC®** adapter is charging; when the LED turns off the **Blu▶LYNC®** is fully charged.

- Talktime: about 14 hours
- Connected Standby Time: 24 hours
- Dongle off Standby Time: 30 days

How to turn **Blu▶LYNC®** on and off

Press and release the power button, the LED **blue** indicator will flash and will flash **red** when it finds the headset it paired with.

Note:

Whenever **Blu▶LYNC®** is turned on it will automatically connect with the last Bluetooth device it was connected with.

To turn it off, press and hold the power button. The LED will turn **red** and then turn off.

Connecting **Blu▶LYNC®** Adapter with a Bluetooth audio accessory

1. Turn on **Blu▶LYNC®**.
2. Press and release the power button 3 times rapidly.
The LED will flash **red** and **blue** alternately while in pairing mode.
3. Put the Bluetooth audio accessory into pairing mode following its pairing/connecting instructions.
4. When the **Blu▶LYNC®** LED starts flashing **blue** only, it is paired and connected with the audio accessory.

Blu▶LYNC® supports the “Headset” Bluetooth audio profile.

List of **Blu▶LYNC®** earpiece functions, operations and status

Function	Button	Status indicator
Turn on	Press once	flashing Blue LED
Turn off	Press and Hold power button 3 sec	Red LED lights then turns off
Pairing Mode	Press 2 times rapidly	Red and Blue LED flashes
Auto connect	When turned on	Red light flashes once

LED Status indicators

Charging cable connected

Indicator	Function
Red light	charging
No light	Fully charged

Charging cable disconnected

Indicator	Function
Red and blue light flashes alternatively	Pairing Mode
Blue light flashes	Powered on

Specifications

Type:	Blu▶LYNC[®] Radio Bluetooth adapter
Bluetooth specification:	V 4.0 CLASS 2
Supported modes:	HSP, SPP and GATT
Frequency range:	2.4 GHz
Operating range:	within 30 feet
Charge time:	1.5~2.5 hours
Talk time:	about 14 hours
Standby time:	about 24 hours

Note: The above stated standby and talk times vary depending on use.

All logos and brand names are the property of their respective trademark owners.
The Bluetooth word mark and logos are owned by the Bluetooth SIG
and used under license by Klein Electronics, Inc.