



---

# Content

Content.....	1
Welcome to the <b>Blu▶LYNC®</b> -TITAN Adapter .....	2
Features.....	3
Charging.....	4
How to turn the <b>Blu▶LYNC®</b> -TITAN Adapter on/off.....	5
Connect <b>Blu▶LYNC®</b> -TITAN with a Bluetooth device.....	6
List of <b>Blu▶LYNC®</b> -TITAN Adapter functions, operations & status ..	7
Status of indicators .....	8
Specifications.....	9

---

# Welcome to the **Blu▶LYNC®-TITAN** Bluetooth Adapter


**Blu▶LYNC®-TITAN** adapter is compact, lightweight and easy to use. Utilizing Low Energy Bluetooth V4.0 chipset it enables faster connections and clearer transmissions. Complete **Blu▶LYNC®-TITAN** adapter by pairing it with the Blu-PTT.

Please read this manual carefully before using the **Blu▶LYNC®-TITAN** adapter.

---

## Blu LYNC®-TITAN Features

1. USB Charging Port
2. Status LED
3. Power/Pairing button
4. Headset Connector



---

## Charging

1. Please fully charge the **Blu▶LYNC®**-TITAN adapter before using it the first time.

2. When the **Blu▶LYNC®**-TITAN adapter is connected to the charger a solid **red** LED light indicates that the **Blu▶LYNC®**-TITAN adapter is charging; when the LED turns off the **Blu▶LYNC®**-TITAN is fully charged.

- Talktime: about 15 hours
- Connected Standby Time: about 72 hours
- Adapter off Standby Time: about 30 days

---

## How to turn **Blu▶LYNC®**-TITAN on and off

Press the power button until the LED indicator lights **blue** and **red**. The indicator will flash **red** until it finds the device it is paired with.

Note:

Whenever **Blu▶LYNC®**-TITAN is turned on it will automatically connect with the last Bluetooth device it was connected with.

To turn it off, press and hold the power button. The LED will turn **red** and then turn off.

---

## Connecting **Blu ▶ LYNC®** -TITAN Adapter with a Bluetooth device

1. Press hold the power button for 6 seconds.

The LED will flash **red** and **blue** alternately while in pairing mode.

2. Put the Bluetooth device into pairing mode following its pairing/connecting instructions.

3. When the **Blu ▶ LYNC®** -TITAN LED starts flashing **blue** only, it is paired and connected.

**Blu ▶ LYNC®** -TITAN supports the "Headset" Bluetooth audio profile.

---

## List of **Blu** **LYNC**<sup>®</sup>-TITAN functions, operations and status

Function	Button	Status indicator
Turn on	Press and hold for 3 seconds	Red and Blue LED
Turn off	Press and Hold for 3 seconds	Red LED lights then turns off
Pairing Mode	Press and Hold for 6 seconds	Red and Blue LED flashes
Auto connect	When turned on	Red light flashes then turns Blue



---

## LED Status indicators

### Charging cable connected


<b>Indicator</b>	<b>Function</b>
Red light	charging
No light	Fully charged

### Charging cable disconnected

<b>Indicator</b>	<b>Function</b>
Red and blue light flashes alternatively	Pairing Mode
Blue light flashes	Powered on
Red light flashes	Lost connection

---

## Specifications

Type:	 -Headset Bluetooth adapter
Bluetooth specification:	V 4.0 CLASS 2
Supported modes:	HSP and GATT
Frequency range:	2.4 GHz
Operating range:	within 30 feet
Charge time:	1.5~2.5 hours
Talk time:	about 15 hours
Standby time:	about 72 hours

Note: The above stated standby and talk times vary depending on use.

All logos and brand names are the property of their respective trademark owners.  
The Bluetooth word mark and logos are owned by the Bluetooth SIG  
and used under license by Klein Electronics, Inc.